



LEEDer Group Sizing Chart -5 CMO

AFO Multi Podus LEEDer BOOT

L-4396 Universal Closures: Only Regular & Large Needed

Size	Measurement	INCHES	Order Code
Regular	Circum. Of Calf to 16	(11 inches from Heel)	LBR
Large	Circum. Of Calf Greater than 16 inches		LBL
Note: Ambulation boot same sizing; add "M" to order code.			LBMR/L

WHFO LEEDer GRIP / Air Assist Grip is one size/side: Order Code = LGAA **L-3807**

Size	Distance Wrist to Elbow Crease	Order Code
Small	Less than 8 inches	LGS-L/R
Medium	8 - 9.5	LGM-L/R
Large	Greater than 9.5	LGL-L/R

WHFO LEEDer REST / Dorsal Resting Hand Splint

L-3807	Width of	Wrist To	Wrist To	Order Code
Size	MP Joint	Finger Tips	Elbow Crease	
Small	2.5 - 3 inches	6 - 7	Less than 8	LRS-L/R
Medium	3 - 3.5	7 - 8	8 - 9.5	LRM-L/R
Large	3.5 - 4	8 - 9.5	Greater than 9.5	LRL-L/R

KO LEEDer KNEE / Air Knee L-1832 or L-1847 (air)

Size	Circumference Measurement	Order Code
Small	Calf 6 - 9 inches	LKS
	Thigh 11 - 16	
Medium	Calf 10 - 13	LKM
	Thigh 16 - 20	
Large	Calf 13 - 16	LKL
	Thigh 20 - 25	

EO LEEDer ELBOW **L-3760**

Size	Circumference Measurement	Order Code
Small	Bicep 8.5 - 10 inches	LES
	ForeArm 7.5 - 9	
Medium	Bicep 10.5 - 13	LEM
	ForeArm 9.5 - 12	
Large	Bicep 13.5 - 16	LEL
	ForeArm 12.5 - 15	